



MULTISPEC ROLLER APPLICATION OVER INTERIOR, VERTICAL FLAT SURFACES (Interior Textured or Damaged Walls)

Step 1/ Required or Optional - Depending on Surface to be Covered - Prep and Prime

Clean surface thoroughly. Using a short nap roller or brush, apply one coat of *Multispec* textured, adhesion promoting basecoat (*SE1 White* for *Multispec WaterColors* or *SE2 Gray* for *Stone Accents*). Basecoat improves *Multispec* rolling properties; particularly over smooth or previously painted surfaces. Textured/absorbent surfaces may not require basecoat.

Step 2 / Required – Apply *Multispec*

Using a *Speckle Effects special* open cell reticulated foam roller cover, roll *Multispec* over the basecoated surface. Load roller fully, roll slowly and gently to minimize spattering and achieve optimal coverage. Use a *Speckle Effects 3"* or corner roller to cut-in and paint corners.

Step 3 / Optional – Apply Clear Topcoat

Apply 2 to 3 coats of high performance, clear protective topcoat such as *Plioshield™* or *Multispec MCT*. First coat will seal *Multispec* to facilitate subsequent cleaning. Second and third coats will enhance durability and impart more gloss. *MCT* is available in gloss and low sheen.

Note

- *Multispec* will be easier to repair and touch-up if only one coat of clear topcoat is applied.
- When using *Multispec WaterColors* which do not contain white flecks, *SE1 White Basecoat* should be tinted to match predominant fleck color in *WaterColors*.
- Allow individual coats to dry thoroughly before recoating.
- Follow manufacturer's label instructions and application guidelines for coatings, equipment and tools.
- For a smooth finish; spray apply *Multispec*. Refer to spray application guideline.

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617