



MULTISPEC

Turning Ordinary Into
The Extraordinary.

MULTISPEC ROLLER APPLICATION DIRECTLY OVER INTERIOR HARD TEXTURED SURFACES (Cinder Block, Cement Block, Sand Textured Latex, Knockdown, Plaster, Brick, Masonry, Stucco, and Adobe)

Step 1 / Required – Apply *Multispec*

Clean surface thoroughly. Using *Speckle Effects* special open cell, reticulated foam roller cover, roll *Multispec* directly over surface.

Step 2 / Optional – Apply Clear Topcoat

Using a short nap roller cover or brush, apply 2-3 coats of high performance, clear protective topcoat such as *Plioshield™* or *Multispec MCT* over *Multispec*. First coat acts as a sealer, while subsequent coats add protection and impart more gloss.

Note

- If surface is previously coated, it may be necessary to first apply *Multispec* textured, adhesion promoting basecoat (*SE1 White* – tinted to match predominant fleck color in *Multispec WaterColors*; or *SE2 Gray* for *Multispec Stone Accents*).
- Allow individual coats to dry thoroughly before recoating.
- Follow manufacturer's label instructions and application guidelines for coatings, equipment and tools.

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617