



## MULTISPEC SPONGE APPLICATION

**Great for Smaller Objects, Decorative Accessories, Lawn and Garden Ornamentation, and Architectural Elements**

**Step 1 / Required – or Optional - Depending on Surface to be Covered - Prep and Prime**  
Clean surface thoroughly. Using a short nap roller or brush, apply one coat of *Multispec* textured, adhesion promoting basecoat (*SE1 White* for *Multispec WaterColors* or *SE2 Gray* for *Stone Accents*). Textured absorbent surfaces may not require basecoat.

**Step 1 / Required – Apply *Multispec***

Using a clean new sponge, dampen slightly with water before dipping into Multispec. Dab on the Multispec with the sponge.

**Step 2 / Optional – Apply Clear Topcoat**

Depending on expected use of item being painted, apply 1 to 3 coats of high performance, clear protective topcoat such as *Plioshield™* or *Multispec MCT*. For exterior applications, like lawn and garden ornaments, use *Plioshield* high performance exterior grade clear protective topcoat.

**Note**

- Allow individual coats to dry thoroughly before recoating.
- When using *Multispec WaterColors* which do not contain white flecks, *SE1 White Basecoat* should be tinted to match predominant fleck color in *WaterColors*.
- Follow manufacturer's label instructions and application guidelines for coatings, equipment and tools.
- For a smooth finish, spray apply *Multispec*. Refer to spray application guidelines.

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617