



MULTISPEC ROLLER APPLICATION OVER EXPOSED EXTERIOR, VERTICAL MASONRY SURFACES (Concrete, Block or Stucco Walls)

Step 1 / Required or Optional - Depending on Surface to be Covered - Prep and Prime

Clean surface thoroughly. Using a short nap roller or brush, apply one coat of *Multispec* textured, adhesion promoting basecoat (SE1 White for *Multispec WaterColors* or SE2 Gray for *Stone Accents*). Basecoat improves *Multispec* rolling properties particularly over smooth or previously painted surfaces. Textured/absorbent surfaces may not require basecoat.

Step 2 / Required – Apply *Multispec*

Using a *Speckle Effects* special open cell reticulated foam roller cover, roll *Multispec* over the basecoated surface. Load roller fully, roll slowly and gently to minimize spattering and achieve optimal coverage. Use a *Speckle Effects* 3” roller cover or corner roller to cut-in and paint corners.

Step 3 / Optional – Apply Clear Topcoat

Apply 2 to 3 coats of high performance, exterior grade, clear water repellent protective topcoat such as *Plioshield*™. First coat will seal the *Multispec* and additional coats will provide greater protection from sunlight and the elements.

Note

- Allow individual coats to dry thoroughly before recoating.
- When using *Multispec WaterColors* which do not contain white flecks, *SE1 White Basecoat* should be tinted to match predominant fleck color in *WaterColors*.
- Follow manufacturer’s label instructions and application guidelines for coatings, equipment and tools.
- For a smooth finish; spray apply *Multispec*. Refer to spray application guidelines

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617