



MULTISPEC SPRAY APPLICATION FOR SMOOTH CONCRETE FLOOR FINISH (Garage or Basement Floors)

Step 1 / Required – Prep and Prime

Etch and neutralize concrete. Clean surface thoroughly. Apply one coat of *Pliosshield*™ clear protective finish to seal the concrete. (If concrete is painted, previous coating should be stripped off, leaving a clean, bare concrete surface before applying *Pliosshield*™.)

Step 2 / Required – Apply *Multispec*

Using suitable HVLP spray equipment, spray apply *Multispec* in one step, cross hatching surface to achieve full-coat *Multispec* coverage and a smooth, even application. See detailed *Multispec* Spray Equipment Guidelines.

Step 3 / Required – Apply Clear Topcoat

Apply 2 to 3 coats of a high performance, clear protective topcoat such as *Pliosshield*™. Apply with a roller, lamb's wool applicator, squeegee or by a pump sprayer. Additional coats will improve the durability of the finish while also imparting more gloss. For extreme durability and a very high gloss finish; a high build, plural component, clear gloss urethane or epoxy should be utilized.

Note

- Allow individual coats to dry thoroughly before recoating.
- Follow manufacturer's detailed label instructions and application guidelines for coatings, equipment & tools.
- For a more textured garage floor finish with better slip resistance; roller apply *Multispec*. Refer to roller application guidelines.

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617