



MULTISPEC SPRAY APPLICATION FOR SMOOTH INTERIOR WALLS

Step 1 / Required – Prep and Prime

Clean surface thoroughly. Using a roller, brush or appropriate spray equipment, prime with a top quality latex primer/sealer.

Step 2 / Required – Apply *Multispec*

Using suitable HVLP spray equipment, spray apply *Multispec* in one step, cross hatching surface to achieve full-coat coverage and a smooth, even application. See detailed *Multispec* Spray Equipment Guidelines.

Step 3 / Optional – Apply Clear Topcoat

Apply 2 to 3 coats of high performance, clear protective topcoat such as *Plioshield*™ or *Multispec MCT*. First coat will seal *Multispec* to facilitate subsequent cleaning. Second and third coats will enhance durability and/or impart more gloss. *MCT* is available in a low sheen finish, well-suited for interior walls.

Note

- For best results when applying *Multispec* over new unpainted drywall, first apply a solvent base primer/sealer/stain killer (e.g. *Zinsser H2O Oil Base Primer Sealer*). New drywall is often manufactured from recycled materials containing ink, which can bleed out and stain or discolor *Multispec*.
- Allow individual coats to dry thoroughly before recoating.
- Follow manufacturer's detailed label instructions and application guidelines for coatings, equipment and tools.
- For a textured finish; roller apply *Multispec*. Refer to roller application guidelines.

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617