



MULTISPEC SPRAY APPLICATION OVER SMOOTH INTERIOR SURFACES LIKE LAMINATE AND TILE (Product Finishing, Kitchen and Bath Renovation)

Step 1 / Required – Prep and Prime

Scuff sand surface and clean thoroughly. Apply a smooth surface primer/bonder such as *XIM 400 White*. Spray apply bonding primer for best results.

Step 2 / Required – Apply *Multispec*

Using suitable HVLP spray equipment, spray apply *Multispec* in one step, cross hatching surface to achieve full-coat coverage and a smooth, even application. See detailed *Multispec* Spray Equipment Guidelines.

Step 3 / Required – Apply Clear Topcoat

Apply high performance, clear two-component aliphatic polyurethane. For best results, spray apply clear topcoat for a smooth finish. (To improve smoothness of finish, lightly scuff and sand between coats.)

Note

- Allow individual coats to dry thoroughly before sanding or recoating.
- Follow manufacturer's detailed label instructions and application guidelines for coatings, equipment and tools.

MULTICOLOR SPECIALTIES, INC. 800/536-5456 Order: 800/362-6617